How do I restart the watch?

Mari Opstad - 2026-03-26 - Comments (0) - Support and service

How do I restart the watch?

You can restart the watch directly from the watch face by entering a specific combination and then turning it on again.

How to do it:

1. Turn on the screen of the watch.
2. Press the following sequence on the watch face:
   12 → 6 → 12 → 12
3. A confirmation will appear on the screen.
4. Press YES. The watch will then turn off.
5. Turn the watch on again by pressing the button on the side of the watch.

The watch will now restart.

Tip:

A restart can help if the watch is not updating its position or is not responding as expected.

Note:

It may take a moment before the watch is ready again after startup.

Related Content

- How do I restore the connection after a lost signal?
- What should I do if the watch is not working?